




Variable Bore Rams, Inc.
 1086 Aillet Rd
 Broussard, LA 70518
 Phone: +1.337.256.5334
 Fax: +1.337.256.8724



Cameron Straight Bore Rams

Bore Size (inches)	7-1/16"	7-1/16"	7-1/16"	11"	11"	11"	13-5/8"	13-5/8"	13-5/8"	16-3/4"	16-3/4"	18-3/4"	18-3/4"	18-3/4"
Working Pressure (psi)	5M	10M	15M	5M	10M	15M	5M	10M	15M	5M	10M	5M	10M	15M
Type	"T"	"T"	"T"	"T"	"T"	"T"	"T"	"T"	"T"	"T"	"T"	"T"	"T"	"T"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	4-1/2"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	5-1/2"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	5-7/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	6-5/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	7-5/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	9-5/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	9-7/8"

Bore Size (inches)	7-1/16"	7-1/16"	7-1/16"	11"	11"	11"	13-5/8"	13-5/8"	13-5/8"	16-3/4"	16-3/4"	18-3/4"	18-3/4"	18-3/4"
Working Pressure (psi)	5M	10M	15M	5M	10M	15M	5M	10M	15M	5M	10M	5M	10M	15M
Type	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"	"TL"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	4-1/2"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	5-1/2"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	5-7/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	6-5/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	7-5/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	9-5/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	*	9-7/8"

Bore Size (inches)	7-1/16"	7-1/16"	7-1/16"	11"	11"	11"	13-5/8"	13-5/8"	13-5/8"	16-3/4"	16-3/4"	18-3/4"	18-3/4"	21-1/4"	21-1/4"
Working Pressure (psi)	5M	10M	15M	5M	10M	15M	5M	10M	15M	5M	10M	5M	10M	2M	5/10M
Type	"U"	"U"	"U"	"U"	"U"	"U"	"U"	"U"	"U"	"U"	"U"	"U"	"U"	"U"	"U"
Straight Range	2-3/8"	2-3/8"	2-3/8"	2-3/8"	2-3/8"	N/A	2-3/8"	2-3/8"	2-7/8"	5-7/8"	5-7/8"	5-1/2"	5-1/2"	5-1/2"	6-5/8"
Straight Range	2-7/8"	2-7/8"	2-7/8"	2-7/8"	2-7/8"	N/A	2-7/8"	2-7/8"	4-1/2"	N/A	N/A	5-7/8"	5-7/8"	6-5/8"	13-5/8"
Straight Range	3-1/2"	3-1/2"	3-1/2"	3-1/2"	3-1/2"	N/A	3-1/2"	3-1/2"	5-1/2"	N/A	N/A	7"	7"	9-5/8"	14"
Straight Range	*	*	*	4"	4"	*	4"	4"	9-7/8"	*	*	7-5/8"	7-5/8"	13-3/8"	*
Straight Range	*	*	*	5"	5"	*	4-1/2"	4-1/2"	10-3/4"	*	*	10-3/4"	10-3/4"	*	*
Straight Range	*	*	*	5-1/2"	5-1/2"	*	5"	5"	*	*	*	11-1/2"	11-1/2"	*	*
Straight Range	*	*	*	7-5/8"	7-5/8"	*	5-1/2"	5-1/2"	*	*	*	*	*	*	*
Straight Range	*	*	*	*	*	*	6-5/8"	6-5/8"	*	*	*	*	*	*	*
Straight Range	*	*	*	*	*	*	7" 7-5/8" 9-5/8" 9-7/8" 10 3/4"	7" 7-5/8" 9-5/8" 9-7/8" 10 3/4"	*	*	*	*	*	*	*

Bore Size (inches)	7-1/16"	7-1/16"	7-1/16"	11"	11"	11"	13-5/8"	13-5/8"	13-5/8"	16-3/4"	16-3/4"	18-3/4"	18-3/4"	18-3/4"
Working Pressure (psi)	5M	10M	15M	5M	10M	15M	5M	10M	15M	5M	10M	5M	10M	15M
Type	"U"	"UH"	"UH"	"UH"	"UH"	"UH"	"UH"	"UH"	"UH"	"UH"	"UH"	"UH"	"UH"	"UH"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	5-1/2"	5-1/2"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	9-5/8"	9-5/8"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	10-3/4"	10-3/4"
Straight Range	*	*	*	*	*	*	*	*	*	*	*	*	13-3/8"	13-3/8"